

KIT: B35-64

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM




Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com

ExhibitAndDisplayTruss.com

KIT: B35-64

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM




Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com

ExhibitAndDisplayTruss.com

KIT: B35-64

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
①	EDT6-BP4	Box Base Plate	6
②	EDT6-B2	2'-0" Box Truss	6
③	EDT6-B3	3'-0" Box Truss	2
④	EDT6-B3-6	3'-6" Box Truss	4
⑤	EDT6-B4	4'-0" Box Truss	4
⑥	EDT6-B2W90	2 Way 90° Junction	4
⑦	EDT6-B3WT	3 Way 90° "T" Junction	2
⑧	EDT6-B3W90	3 Way 90° Junction	2
⑨	EDT6-EHC1	Extender Hook Clamp	6
⑩	EDT2-STB3	3' Single Tube Brace	2
⑪	EDT2-ST3-6	3'-6" Single Tube	2
⑫	EDT1-ST4	4'-0" Single Tube	2


©2015 EXHIBIT AND DISPLAY TRUSS.COM

EXPLODED VIEW

KIT: B35-64

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM




TOP VIEW
UNITS: FEET & INCHES

©2015 EXHIBIT AND DISPLAY TRUSS.COM

KIT: B35-64

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM



Single Tube Braces for Banner support.
Extender Hook Clamps allow for adjustable heights.

FRONT VIEW
UNITS: FEET & INCHES


©2015 EXHIBIT AND DISPLAY TRUSS.COM

KIT: B35-64

6" Wide Aluminum Truss. 1" Chords with 5/16" Webs

©2015 EXHIBIT AND DISPLAY TRUSS.COM

©2015 EXHIBIT AND DISPLAY TRUSS.COM



SIDE VIEW
UNITS: FEET & INCHES

Single Tube Braces for Banner support.
Extender Hook Clamps allow for adjustable heights.

Toll Free: 855-323-4866
Email: info@exhibitanddisplaytruss.com

ExhibitAndDisplayTruss.com